


GekTV IPTV Receiver GEK1080HD-160G

Network Setup Guide

When you first turn on the GekTV IPTV Receiver, it will try to determine the best network setting for you automatically. When it fails to detect a proper network setup, it will present you with the Network Setup screen as seen below:




This screen shows you the Current Configuration and also allows you to change parameters to fit your home setting. Select the proper Network Setup Type (Static IP, DHCP, PPPoE, or WiFi) and press **OK**.

DHCP Setup


Due to the nature of DHCP setting, there is nothing to configure.

Static IP Setup



You will need to obtain the following list of parameters from your network administrator. To input the parameters, navigate to the desired field using the up/down arrow on the remote control, then use the number key pad to enter the numbers. IP address separators are entered by the **▶▶** button. When setting is done correctly, press the **OK** button to save the parameters and use this network setting. To cancel the operation, press the **◀** button to go back to the previous page.

PPPoE Setup



If you connect the GekTV IPTV Receiver directly to your ADSL modem (without going through any home router), you may need to use PPPoE as your Network Setup type. Obtain the necessary

username and password from your Internet Service Provider (ISP) and fill it in.

You can input alphanumeric characters using the number keys on the remote control. Please refer to the following table to select your code:

Key	1 st press	2 times	3 times	4 times	5 times	6 times	7 times	8 times	9 times
1	1	.	,	!	?	+	-	*	/
2	2	a	b	c	A	B	C	()
3	3	d	e	f	D	E	F	{	}
4	4	g	h	i	G	H	I	[]
5	5	j	k	l	J	K	L	<	>
6	6	m	n	o	M	N	O	:	;
7	7	p	q	r	P	Q	R	~	^
8	8	t	u	v	T	U	V	~	^
9	9	w	x	y	Z	X	Y	Z	
0	0	@	#	\$	%	&	^	_	=

You may use the **▶▶** button to backspace through your typed characters.